




CABINET PARTS

For Models: ET21PKXFW00, ET21PKXFN00
(White) (Almond)

REFRIGERATOR



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Models: ET21PKXFW00, ET21PKXFN00
(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1		Cabinet (Not A Serviceable Part)
2	2157591	Hinge (Top)
3	2166108	Roller-Front (2)
4	489459	Screw
5	489385	Clamp, Tube (Water Supply Line)
10	2179826	Rivet
11	2174650	Screw
12	549193	Clamp-Cord
15	489423	Screw
16	2183064	Hinge, Center
17	2163757	Shim, Hinge Center
18	489464	Screw
20	2179829	Hinge Butt
23	2172745	Shim, Bottom Hinge
24		Fitting, Water Tube (Not Serviced)
27		Hole Plug (6)
	2151652	White
	2151653	Almond
31	2166251	Cover, Valve
35		Corner Filler (2)
	2163733	White
	2166187	Almond
36		Grille
	2189154	White
	2189156	Almond
38	487576	Washer
39	1123517	Shim
40		Cover-Hinge
	2160403	White
	2160404	Almond
41		Rail, Center (Not Serviced)
42		Corner Filler, Grille
	2166156	White
	2166204	Almond
43	2183063	Pin, Hinge
44	2189060	Cover, Unit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: ET21PKXFW00, ET21PKXFN00
 (White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


DOOR PARTS

For Models: ET21PKXFW00, ET21PKXFN00
 (White) (Almond)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes #9 & #22)	12	9791769	Cover, Screw White	26	2183805	Bracket, Door Stop
	2183920	White	9791770		Almond	27	488921	Screw
	2183921	Almond	13		Nameplate	28		Hole Plug
2		End Cap	2175383		White Model		844478	White
	2183141	White	2175384		Almond Model		989196	Almond
	2183142	Almond	16	2195378	Trim, Door Shelf	29	2156007	Plug-Trim
4		End Cap, Handle (2)	17	489028	Screw	30	2159300	Plug-Trim
	9791771	White	19		Freezer Door (Includes #22 & #23)	31	2177130	Compartment Door Handle, F.C.
5		Handle Center	2182489		White		2171043	White
	2148035	White	2184400		Almond		2171044	Almond
	2148036	Almond	20		Hole Plug	36	944035	Bracket, Door Stop
6	489006	Screw	2189000		White	37	2171265	Trim-Door (2)
7	943188	Spacer	2189008		Almond	38	943187	Shim
8	487909	Screw	2159304		Shelf, Flip-Up	39		Handle End
9		Door Gasket, Magnetic	22	2183003	Thimble		9791776	White
	2159061	Mist Beige	23		Door Gasket, Magnetic		9791777	Almond
			25	2159060	Mist Beige	41	2156002	Endcap (4)
				2195395	Bin, Door Shelf (3)	42	2177261	Trim, Door

LINER PARTS

For Models: ET21PKXFW00, ET21PKXFN00
 (White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LINER PARTS


For Models: ET21PKXFW00, ET21PKXFN00
(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	531933	Grommet (2)
3	2184634	Gasket, Evaporator Cover (Side)
4	2193084	Timer, Defrost
5	549512	Thermostat Tube Barrier
6	941839	Hole Plug
7	2193493	Wire Assy. Control Box
8	2162085	Socket, Light (2)
9	2179858	Damper, Air
10	2183833	Fan Motor
11	2163777	Fan Blade
12	2179790	Control Box
13	2197536	Thermostat Assy. (Includes Items 5, 18 & 36)
14	489478	Screw
15	489412	Screw
16	2189823	Cover-Evaporator
17	527949	Light Bulb (2)
18	2163802	Weight, Thermal
19	1118894	Switch, Rocker Arm
20	2179859	Post, Damper
21	2176281	Cover, Air Diffuser
22	2193455	Knob, Thermostat
23	2182340	Air Tower
24	2197534	Air Diffuser, Bottom
25	2184617	Freezer Floor
26	2179877	Air Diffuser, Top
27	2190688	Cover, Hole
29	2163827	Bracket, Fan Motor
30	2184635	Gasket, Evaporator Cover (Top)
31	2174629	Air Return & Foil Assembly
32	487996	Cap
33	2176341	Clip, Defrost Timer
34	2176297	Knob, Damper
35	2163810	Bracket, Damper Knob
36	2172532	Seal, Rear Thermostat
38	2171931	Valve, Release
39	2195656	Wire Assembly, Freezer Compartment

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: ET21PKXFW00, ET21PKXFN00
 (White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS


For Models: ET21PKXFW00, ET21PKXFN00
(White) (Almond)




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

SHELF PARTS

For Models: ET21PKXFW00, ET21PKXFN00
 (White) (Almond)



Illus. No.	Part No.	DESCRIPTION
1	2163756	Shelf, Ladder (2)
2	2163826	Shelf, Ladder Center
3	2163762	Cup, Shelf Mtg.
4	520965	Screw Support
5	489415	Screw
6	2169933	Egg Bin
7	2174693	Glass, Full Shelf
8	2163885	Trim, Shelf Rear
9	2195344	Crisper Cover
10	2163860	Shelf, Cantilever
11	2176225	Insert, Crisper Cover
12	2176306	Pan, Shelf Cantilever
13	2174694	Glass, Shelf
14	2176263	Trim, Shelf Front
15	2163832	Crisper Support
16	2163863	Shelf, Full Cantilever
17	2184667	Shelf, Freezer
18	2163883	Trim, Shelf Rear
20	2195403	Pan, Meat
22	841180	Ice Tray (2)
24	2190601	Crisper Pan



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LITERATURE AND OPTIONAL PARTS

For Models: ET21PKXFW00, ET21PKXFN00
 (White) (Almond)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
Parts Not Illustrated and Optional Parts (Not Included)								
Miscellaneous								
978941	Insulation, Fiberglass (63-1/2" x 35-1/2" x 2-5/8")		*350942	Primer, White (13 Oz. Spray Can)				LITERATURE PARTS
212643	Sealer, Gum (4 Feet)		*350939	Enamel, Black (13 Oz. Spray Can)		LIT2195481		Service & Wiring Sheet
479502	Tape, Vinyl (3/4" x 108")		*350930	Enamel, White (13 Oz. Spray Can)		LIT2195607		Energy Label
876305	Kit, Insulation (14 Pcs. 3" x 24" x 48")		*350956	Enamel, Almond (13 Oz. Spray Can)		LIT2195369		Use & Care Guide
876370	Kit, Insulation (2 Pcs. 3" x 24 " x 48")		72017	Brush Touch-Up Kit (White)				
876029	Kit, Foam Slab (30" x 32-1/2" x 1-1/2")		72032	Brush Touch-Up Kit (Black)				
505587	Sealer, Mastic (1 Qt.)		72107	Brush Touch-Up Kit (Almond)				
511873	Touch-Up, White Porcelain (2 Oz.)							
542638	Grease, Silicone (1/2 Oz.)							
542639	Cement, Alumilastic (1-1/4 Oz.)							
606755	Bag, Insulation (36-5/8" x 46")							
799833	Kit, Evaporator Repair (Aluminum Epoxy)							
799832	Kit, Porcelain Repair (White)							
503695	Cork Sealer (1/4 Pound)							
2172516	Door Reversal Instructions							
Customer Touch-Up Material								
Refinishing Material								
*Caution: The Spray Paint Is Not To Be Used Where The Paint May Make Contact With The Door Gaskets								
Following May Be Purchased								
DO-IT-YOURSELF REPAIR MANUALS								
LIT677969 Do-It-Yourself Manual Ref./Fzr.								
LIT677971 Do-It-Yourself Manual, Icemaker								
ICE MAKER FIELD INSTALLABLE								
ECKMF94								
TORX SCREW WRENCH								
1117510 Torx Key								

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST